# **ACCESS VALVES**

#### EVACUATION AND CORE REMOVER TOOLS



Specifically designed to valve off the system to remove valve core, these tools feature a quarter turn ball valve shut-off and o-ring seals.

The valve core can be completely removed and replaced without losing system charge. Speed-up evacuation, recovery, or recharging time through the full-flow port. Both tools have a storage area to house spare valve cores.

| VALVE CORE REMOVER TOOL |  |           |           |  |
|-------------------------|--|-----------|-----------|--|
| PART NO.                | QUICK CONNECT                            | FLARE RUN | SIDE PORT |  |
| A32500N                 | 1/4"                                     | 1/4"      |           |  |
| A32505N                 | 5/16"                                    | 1/4"      |           |  |
| A32525N                 | 1/4"                                     | 1/4"      | 1/4"      |  |
| A32530N                 | 5/16"                                    | 1/4"      | 1/4"      |  |
| A32535N                 | 5/16"                                    | 5/16"     | 1/4"      |  |
| A32501N                 | Core remover bit for A32500N replacement |           |           |  |
| A32504                  | Core remover bit for A32525N replacement |           |           |  |



#### **EVACUATION RECOVERY TOOL**

Our evacuation/recovery tool is a plier-type tool with a quick release trigger which punctures large holes into the line for discharge of a recovery unit. Fits 3/16" to 7/8" OD hard tubing.

| EVACUATION RECOVERY TOOL |      |                                  |
|--------------------------|------|----------------------------------|
| PART NO.                 | QTY. | DESCRIPTION                      |
| A32100                   | 1    | Evacuation/recovery tool         |
| A32101                   | 1    | Hardened steel needle and gasket |



## **VALVE CORE TORQUE TOOL**

Our valve core torque tool automatically sets proper torque to 5 pounds. Calibrated to precise torquing requirements for core valves, the tool will no longer tighten once proper torque is achieved. Eliminates guess work which results in under- and over-torquing. Works with all Schrader valve cores.

| VALVE CORE TORQUE TOOL |      |  |
|------------------------|------|--|
| PART NO.               | QTY. | DESCRIPTION                                |
| A32008                 | 1    | 1/4" Valve core torque tool                |
| A32008-B               | 12   | 1/4" Valve core torque tool bulk           |
| A32008-BX              | 12   | 1/4" Valve core torque tool in display box |



### 1/4" VALVE CORES AND TOOL

PTFE/neoprene seal replacement valve core; max 800 psi and 220°F (104°C)

\*USA

| 1/4" VALVE CORES AND TOOL |      |   |
|---------------------------|------|---|
| PART NO.                  | QTY. | DESCRIPTION   |
| A32004                    | 1    | 1/4" Valve core tool with storage for 6 valve cores |
| A31999                    | 5    | 1/4" Valve cores                                    |
| A31999-25                 | 25   | 1/4" Valve cores                                    |
| A31999-100                | 100  | 1/4" Valve cores                                    |

