

3 YEAR WARRANTY. The manufacturer disclaims all implied and express warranties, including the implied warranty of fitness for a particular purpose, except as follows: The EZ-Trap condensate trap or overflow switch purchased by you is unconditionally warranteed to be free from defects in material and workmanship under normal use for a period of three (3) years from date of purchase, providing it is installed and operated strictly in accordance with manufacturer's installation instructions. If the product is found to be defective or otherwise fails in normal use, you may return it for replacement. All freight charges for the return of the product shall be borne by you. The manufacturer will pay outgoing freight charges for the replacement product. Defective products returned to the factory prepaid will be repaired or replaced free of charge. Replacement product will, to the extent such product is then available in manufacturer's inventory, be of similar type, color and kind. Manufacturer retains the right to substitute product if replacement product does not conform in terms of color, type and specifications to the original product, if no longer available. This warranty does not cover replacement labor or any cost, claim or incident to any odefect nor does it cover freezing or any other consequential damages. The sole liability of the manufacturer under this warranty is limited to the replacement of defective product. Product damaged by improper use, accident, neglect, alteration, abuse or improper installation is excluded from this warranty.

RectorSeal® 2601 Spenwick Drive - Houston, TX 77055 ph: 713.263.8001 - 800.231.3345 fax: 713.263.7577 - 800.441.0051 www.rectorseal.com - Like Us on Facebook





Installation Instructions

Model No.

83113 EZT113)

From Drain Pan Outlet 🕨

Trap Assembly Instructions

- and Cross Tee (C) to required angles for installation. Dry fit, and mark components, rotating U-Bend (B)
- Glue components (A thru C) using dry fit markings. Then glue assembly into Drain Pan Line
- Drain Line must exit building with at least a 5° angle. Glue Drain Line (E) into center leg of Outlet Tee (C).
- 4. Check that Red Cap (D) are tightly secured.
- 5. Attach cleaning label as indicated.
- Note: Insulation is required when trap is installed in unconditioned space where sweating can occur.

Important:

with RectorSeal instructions Install in strick accordance local plumbing, drainage as well as all applicable and electrical codes.

