



You can automate your system to do many things. This guide will walk you through triggering your camera to record.

DOOR / WINDOW SENSOR TRIGGERS INDOOR CAMERA TO RECORD

STEP 1

After logging into the site, _ select Settings from the hamburger menu on the top left. Select Automation (Scenes) from the drop down menu in the Settings menu.



STEP 2

Select the next available scene, "X Scene" and name your automaton. Be sure to select a name that is intuitive to the homeowner.

STEP 3

Select Always On and decide what triggers the action (i.e. the door opens = sensor open).

Next, select which sensor (i.e. front, side, window, closet) initiates the action.



STEP 4

In Scene Result 1, select Alarm System from the drop down menu. Next, select Trigger Camera Video Clip in the Action Type drop down menu. Check the box of which camera you want to record and hit Save. Your automation is now created.

©2017 CôrTM Home Automation 7/2017